
P797 Cupboard knob



P797

P787-A, B or C P797-A, B or C Cupboard knob



Knob Ø: A = 19mm; $^{3}/_{4}$ " B = 25mm; 1 " C = 32mm; $^{11}/_{4}$ " **Projection (P787):** A = 30mm; $^{13}/_{16}$ " B = 38mm; $^{11}/_{2}$ " C = 47mm; $^{17}/_{8}$ "

(P797): A = 34mm; 1³/8" B = 42mm; 1¹¹/₁₆" C = 54mm; 2¹/₈"

Base Ø (P797): A = 22mm; $^{7}/8''$ B = 29mm; $^{11}/8''$ C = 35mm; $^{17}/16''$

Fixing: Concealed, M4 x 40mm; 1⁵/8" screw

UK and Worldwide Customer Service Team: +44 (0)121 766 4200 www.samuel-heath.co.uk

USA Customer Service Team: www.samuel-heath.com